



- Product installation must be carried out by a qualified professional.
- installing Opaline Flex, power **ON** the strip for 15 minutes until it softens.
- Before installing, make sure that electrical power is turned **OFF**.
- Before installing, ensure that the area can bear the total weight of the luminaire.
- Pay attention to polarity when connecting the product.
- Do not operate if the luminaire has been damaged.
- During installation, use gloves to protect the surface from dirt and fingerprints.
- Product warranty does not cover damage due to faulty installation and/or misuse.
- For further information, please contact Architape.



